



IMPORTANT NOTE FOR MEDIUM RESOLUTION MONITORS: WHEN THE GAME IS FIRST TURNED ON, THE BOOT UP TEXT WILL BE GARBLED AND UNREADABLE. THIS IS EXPECTED. THE VIDEO WILL SYNC UP WHEN IT COMPLETES THE BOOT

Switch Wiring Example



Coin Counter



- A: Audio Cables
- B: I/O Power Cable
- C: +12 volts ANTENNA BOOSTER
- D: AC Power Cable
- E: AC Selector Switch
- F: ON/Off Switch
- G: USB I/O Cable (top port)
- H: Cabinet Identification Device (CID)
- I: USB CID Cable (bottom port)
- J: USB Update Device Cable
- K: Video Cable
- L: I/O Board
- M: JAMMA Harness
- N: Trackball Interconnect Cable
- O: Trackball
- P: Card Reader

